


AUTOSLIDE

Using your AutoSlide 4-Button Remote LSG0 7.22.20



The AutoSlide 4-Button Remote offers you full wireless control over an AutoSlide unit:

- **Pet [top button]:** Triggers the Pet Sensor of the unit. Note that this button will only work if the unit is in Pet Mode, and will open the door to the programmed pet width.
- **Master [left button]:** Triggers the Inside Sensor of the unit. This will trigger the unit to open in all modes but Blue mode.
- **Stack [right button]:** Triggers the Stacker Sensor of the unit. This will trigger the unit to start, stop, and reverse in Blue mode.
- **Mode [bottom button]:** Changes the mode (Green Mode, Blue Mode, Red Mode, Pet Mode) of the unit.

Note: In previous versions of the remote, right button triggered Outside Sensor of the unit. This triggers the unit in Green and Pet mode only.

AutoSlide Unit Pairing Instructions:


1. Remove the unit's cover to access the control panel. Press the Sensor Learn button on the control panel; the light next to it should turn red. Now press any button on the 4-Button Remote.
2. Press the Sensor Learn button again - the Sensor Learn light should flash three times. Press any button on the 4-Button Remote again. The Sensor Learn light should now turn off.
3. Confirm it's paired by pressing either the Mode button or Master button on the 4-Button Remote.

A video of this process can be found at: youtu.be/y4WovHxJUAQ

Note: if the remote ever fails to pair and/or has stopped functioning (no blue light), it may need a battery change. Each 4-Button Remote takes 1x Alkaline 27A 12V Battery.



(Actual Size)



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
 - Increase the separation between the equipment and receiver.**
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
 - Consult the dealer or an experienced radio/TV technician for help.**
- To assure continued compliance, any changes or modifications not expressly approved by the party.**

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and**
- (2) This device must accept any interference received, including interference that may cause undesired operation**